

MIDI POWER CONTROL SYSTEM



WIRING DIAGRAM

12-11-2015

Heartland

Exact Location of Breakers not Critical
As long as Current Sensor screw terminals
L1 & L2 are on opposite phases of Line Voltage.

Part #: 00-10050-354
Reference ID: 354 3AC 5.5KGEN151
Program Options:
Relay Shed Order:
4-A/C-FRT
5-A/C-MID
3-A/C-RR
1-(Relay 1 unused)
2-(Relay 2 unused)
50A Service = Sleep Mode
GEN =45A Current Limit
Shed Loads

