

MIDI POWER CONTROL SYSTEM



WIRING DIAGRAM 1-26-23 Brinkley

Exact Location of Breakers not Critical
As long as Current Sensor screw terminals
L1 & L2 are on opposite phases of Line Voltage.

Part #: 00-10050-363
Reference ID: 363 3AC 5.5KG221
Program Options:
Relay Shed Order:
4-A/C-Garage
3-A/C-Bed
5-A/C-Main
1-(Relay 1 unused)
2-(Relay 2 unused)
50A Service = Sleep Mode
GEN =45A Current Limit
Shed Loads

